
1 1/2" Elima-Matic Bolted Metallic

with Metallic Center Section

E40

E40 Metallic Pumps

- Aluminum
- Cast Iron
- Stainless Steel



Safety Information

IMPORTANT



Read the safety warnings and instructions in this manual before pump installation and start-up. Failure to comply with the recommendations stated in this manual could damage the pump and void factory warranty.



When the pump is used for materials that tend to settle out or solidify, the pump should be flushed after each use to prevent damage. In freezing temperatures the pump should be completely drained between uses.

CAUTION



Before pump operation, inspect all fasteners for loosening caused by gasket creep. Retighten loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



Nonmetallic pumps and plastic components are not UV stabilized. Ultraviolet radiation can damage these parts and negatively affect material properties. Do not expose to UV light for extended periods of time.

WARNING



When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. Be certain that approved eye protection and protective clothing are worn at all times. Failure to follow these recommendations may result in serious injury or death.



Airborne particles and loud noise hazards. Wear eye and ear protection.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product that is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe containment.




Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers and other miscellaneous equipment must be properly grounded.



This pump is pressurized internally with air pressure during operation. Make certain that all fasteners are in good condition and are reinstalled properly during reassembly.

Grounding the Pump

To be fully groundable, the pumps must be ATEX Compliant. Refer to the nomenclature page for ordering information.



Optional 8 foot long (244 centimeters) Ground Strap is available for easy ground connection.

To reduce the risk of static electrical sparking, this pump must be grounded. Check the local electrical code for detailed grounding instruction and the type of equipment required.

Refer to nomenclature page for ordering information.

WARNING



Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.



Table of Contents

SECTION 1: PUMP	SPECIFICATIONS1
------------------------	-----------------

- Nomenclature
- Performance
- Materials
- Dimensional Drawings

SECTION 2: INSTALLATION & OPERATION.....5

- Principle of Pump Operation
- Typical Installation Guide
- Troubleshooting

SECTION 3: EXPLODED VIEW.....8

- Composite Drawings
- Parts List
- Materials Code


SECTION 4: WARRANTY & CERTIFICATES12

- Warranty
- CE Declaration of Conformity Machinery



Explanation of Pump Nomenclature

Your Serial #: (fill in from pump nameplate)



Model	Pump Size	Wetted Parts	Non-Wetted Parts	Diaphragm Material
E Elima-Matic	6 1/4"	A Aluminum	A Aluminum	1 Neoprene
U Ultra-Matic	8 3/8"	C Cast Iron	S Stainless Steel	2 Nitrile (Nitrile)
V V-Series	5 1/2"	S Stainless Steel	P Polypropylene	3 FKM (Fluorocarbon)
RE AirVantage	7 3/4"	H Alloy C	G Groundable Acetal	4 EPDM
	1 1"	P Polypropylene	Z PTFE-coated Aluminum	5 PTFE
	40 1-1/2" Full Flow	K Kynar	J Nickel-plated Aluminum	6 Santoprene XL
	4 1-1/4" or 1-1/2"	G Groundable Acetal	C Cast Iron	7 Hytrel
	2 2"	B Aluminum (screen mount)	Q Epoxy-Coated Aluminum	9 Geolast
	3 3"			
	3 3			

Diaphragm Series Valve Ball Material Valve Seat/Valve Seat O-Ring Material Construction Design R Rugged 1 Neoprene 1 Neoprene

2 Nitrile 2 Nitrile X Thermo-Matic 3 (FKM) Fluorocarbon 3 (FKM) Fluorocarbon 4 EPDM 4 EPDM T Tef-Matic (2-piece) **B** Versa-Tuff (1-piece) 5 PTFE 5 PTFE F FUSION (one-piece 6 Santoprene XL 6 Santoprene XL integrated plate) 7 Hytrel 7 Hytrel 8 Polyurethane 8 Polyurethane 9 Geolast 9 Geolast

A Acetal A Aluminum w/ PTFE O-Rings S Stainless Steel S Stainless Steel w/ PTFE O-Rings C Carbon Steel w/ PTFE O-Rings H Alloy C w/ PTFE O-Rings

T PTFE Encapsulated Silicone O-Rings

VERSA-MATIC® VME40msm-rev1011

9 Bolted

0 Clamped

D Dome

Materials

Material Profile:		Operating Temperatures:	
CAUTION! Operating temperature limitations are as follows:	Max.	Min.	
Conductive Acetal: Tough, impact resistant, ductile. Good abrasion resistance and low friction surface. Generally inert, with good chemical resistance except for strong acids and oxidizing agents.	190°F 88°C	-20°F -29°C	
EPDM: Shows very good water and chemical resistance. Has poor resistance to oils and solvents, but is fair in ketones and alcohols.	280°F 138°C	-40°F -40°C	
FKM: (Fluorocarbon) Shows good resistance to a wide range of oils and sovents; especially all aliphatic, aromatic and halogenated hydrocarbons, acids, animal and vegetable oils. Hot water or hot aqueous solutions (over 70°F) will attack FKM.	350°F 177°C	-40°F -40°C	
Hytrel®: Good on acids, bases, amines and glycols at room temperatures only.	220°F 104°C	-20°F -29°C	
Neoprene: All purpose. Resistance to vegetable oils. Generally not affected by moderate chemicals, fats, greases and many oils and solvents. Generally attacked by strong oxidizing acids, ketones, esters and nitro hydrocarbons and chlorinated aromatic hydrocarbons.	200°F 93°C	-10°F -23°C	
Nitrile: General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C	
Nylon: 6/6 High strength and toughness over a wide temperature range. Moderate to good resistance to fuels, oils and chemicals.	180°F 82°C	32°F 0°C	

Polypropylene: A thermoplastic polymer. Moderate tensile and flex strength. Resists stong acids and alkali. Attacked by chlorine, fuming nitric acid and other strong oxidizing agents.	180°F 82°C	32°F 0°C
PVDF: (Polyvinylidene Fluoride) A durable fluoroplastic with excellent chemical resistance. Excellent for UV applications. High tensile strength and impact resistance.	250°F 121°C	0°F -18°C
Santoprene®: Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	275°F 135°C	-40°F -40°C
UHMW PE: A thermoplastic that is highly resistant to a broad range of chemicals. Exhibits outstanding abrasion and impact resistance, along with environmental stress-cracking resistance.	180°F 82°C	-35°F -37°C
Urethane: Shows good resistance to abrasives. Has poor resistance to most solvents and oils.	150°F 66°C	32°F 0°C
Virgin PTFE: (PFA/TFE) Chemically inert, virtually impervious. Very few chemicals are known to chemically react with PTFE; molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	220°F 104°C	-35°F -37°C

Maximum and Minimum Temperatures are the limits for which these materials can be operated. Temperatures coupled with pressure affect the longevity of diaphragm pump components. Maximum life should not be expected at the extreme limits of the temperature ranges.

Metals:

Alloy C: Equal to ASTM494 CW-12M-1 specification for nickel and nickel alloy.

Stainless Steel: Equal to or exceeding ASTM specification A743 CF-8M for corrosion resistant iron chromium, iron chromium nickel and nickel based alloy castings for general applications. Commonly referred to as 316 Stainless Steel in the pump industry.

For specific applications, always consult the Chemical Resistance Chart.

AFTERMARKET PARTS

RIGHT PART, RIGHT NOW

Pumper Parts is your single source for parts that fit Air-Operated Double Diaphragm (AODD) pumps

- Wilden®
- ARO®
- Yamada®

Designed to perform equal to or greater than original equipment manufacture.



Phone: (419) 526-7296 info@pumperparts.com www.pumperparts.com

Pumper Parts and its products are not affiliated with any of the original equipment manufacturers referenced herein. All original equipment manufacturers names, colors, pictures, descriptions and part numbers are used for identification purposes only. Pumper Parts[®] is a registered trade name of IDEX Corporation. All other trademarks, registered trademarks and product names are the property of their respective owners. Yamada[®] is a registered trade name of Ingersoll-Rand Company. Wilden[®] is a registered trade name of Wilden Pump and Engineering Company, a Dover Resources Company.

VERSA-MATIC®
VME40msm-rev1011


WWW.VERSAMATIC.COM Model E40 Metallic • 2

Performance

E40 1 1/2" Bolted Pump- Metallic Center ELASTOMERIC AND TPE FITTED

**w/ Stainless Center add 21 lbs (9.5 kg)

Rubber and TPE Fitted



NOTE: Performance based on the following: elastomeric fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.


E40 1 1/2" Bolted Pump - Metallic Center PTFE Fitted

Flow Rate Adjustable to 0-103 gpm (389.9 lpm) **Port Size** Suction 1 1/2" NPT Discharge 1 1/2" NPT **Suction Lift** Wet......29' (8.8 m) Max Solid Size (Diameter) Max Noise Level 98 dB(A) **Shipping Weights** Aluminum 55 lbs (25 kg) Cast Iron. 95 lbs (43 kg)

Stainless Steel 92 lbs (42 kg)

**w/ Stainless Center add 21 lbs (9.5 kg)

PTFE Fitted



NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.





Dimensional Drawings


E40 Metallic Center

Dimensions in inches (metric dimensions in brackets)

The dimensions on this drawing are for reference only. A certified drawing can be requested if physical dimensions are needed.








BOTTOM VIEW



Principle of Pump Operation



Air-Operated Double Diaphragm (AODD) pumps are powered by compressed air, nitrogen or natural gas.


The main directional (air) control valve ① distributes compressed air to an air chamber, exerting uniform pressure over the inner surface of the diaphragm ②. At the same time, the exhausting air ③ from behind the opposite diaphragm is directed through the air valve assembly(s) to an exhaust port ④.

As inner chamber pressure **(P1)** exceeds liquid chamber pressure **(P2)**, the rod ⑤ connected diaphragms shift together creating discharge on one side and suction on the opposite side. The discharged and primed liquid's directions are controlled by the check valves (ball or flap)⑥ orientation.

The pump primes as a result of the suction stroke. The suction stroke lowers the chamber pressure **(P3)** increasing the chamber volume. This results in a pressure differential necessary for atmospheric pressure **(P4)** to push the fluid through the suction piping and across the suction side check valve and into the outer fluid chamber T.

Suction (side) stroking also initiates the reciprocating (shifting, stroking or cycling) action of the pump. The suction diaphragm's movement is mechanically pulled through its stroke. The diaphragm's inner plate makes contact with an actuator plunger aligned to shift the pilot signaling valve. Once actuated, the pilot valve sends a pressure signal to the opposite end of the main directional air valve, redirecting the compressed air to the opposite inner chamber.


SUBMERGED ILLUSTRATION



Pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills.



Recommended Installation Guide



Installation And Start-Up

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

Air Supply

Connect the pump air inlet to an air supply with sufficient capacity and pressure to achieve desired performance. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

Air Valve Lubrication

The air distribution system is designed to operate WITHOUT lubrication. This is the standard mode of operation. If lubrication is designed, install an air line lubricator set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes. Consult the Performance Curve to determine air consumption.

Air Line Moisture

Water in the compressed air supply may cause icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer.

Air Inlet And Priming

To start the pump, slightly open the air shut-off valve. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.




Troubleshooting Guide

Symptom:	Potential Cause(s):	Recommendation(s):
Pump Cycles Once	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Air valve or intermediate gaskets installed incorrectly.	Install gaskets with holes properly aligned.
	Bent or missing actuator plunger.	Remove pilot valve and inspect actuator plungers.
Pump Will Not Operate	Pump is over lubricated.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
/ Cycle	Lack of air (line size, PSI, CFM).	Check the air line size and length, compressor capacity (HP vs. cfm required).
/ Oyulc	Check air distribution system.	Disassemble and inspect main air distribution valve, pilot valve and pilot valve actuators.
	Discharge line is blocked or clogged manifolds.	Check for inadvertently closed discharge line valves. Clean discharge manifolds/piping.
	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Blocked air exhaust muffler.	Remove muffler screen, clean or de-ice, and re-install.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Pump chamber is blocked.	Disassemble and inspect wetted chambers. Remove or flush any obstructions.
Pump Cycles and Will	Cavitation on suction side.	Check suction condition (move pump closer to product).
Not Prime or No Flow	Check valve obstructed. Valve ball(s) not seating properly or sticking.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Clean out around valve ball cage and valve seat area. Replace valve ball or valve seat if damaged. Use heavier valve ball material.
	Valve ball(s) missing (pushed into chamber or manifold).	Worn valve ball or valve seat. Worn fingers in valve ball cage (replace part). Check Chemical Resistance Guide for compatibility.
	Valve ball(s)/seat(s) damaged or attacked by product.	Check Chemical Resistance Guide for compatibility.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
Pump Cycles Running	Over lubrication.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
Sluggish/Stalling,	Icing.	Remove muffler screen, de-ice, and re-install. Install a point of use air drier.
Flow Unsatisfactory	Clogged manifolds.	Clean manifolds to allow proper air flow
Tiow offsatisfactory	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Cavitation on suction side.	Check suction (move pump closer to product).
	Lack of air (line size, PSI, CFM).	Check the air line size, length, compressor capacity.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Air supply pressure or volume exceeds system hd.	Decrease inlet air (press. and vol.) to the pump. Pump is cavitating the fluid by fast cycling.
	Undersized suction line.	Meet or exceed pump connections.
	Restrictive or undersized air line.	Install a larger air line and connection.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs. Purging the chambers of air can be dangerous.
Product Leaking	Diaphragm failure, or diaphragm plates loose.	Replace diaphragms, check for damage and ensure diaphragm plates are tight.
Through Exhaust	Diaphragm stretched around center hole or bolt holes.	Check for excessive inlet pressure or air pressure. Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
Premature Diaphragm	Cavitation.	Enlarge pipe diameter on suction side of pump.
Failure	Excessive flooded suction pressure.	Move pump closer to product. Raise pump/place pump on top of tank to reduce inlet pressure. Install Back pressure device (Tech bulletin 41r). Add accumulation tank or pulsation dampener.
	Misapplication (chemical/physical incompatibility).	Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
	Incorrect diaphragm plates or plates on backwards, installed incorrectly or worn.	Check Operating Manual to check for correct part and installation. Ensure outer plates have not been worn to a sharp edge.
Unbalanced Cycling	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
, ,	Undersized suction line.	Meet or exceed pump connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs.

For additional troubleshooting tips contact After Sales Support at service.warrenrupp@idexcorp.com or 419-524-8388



Composite Repair Parts Drawing



Composite Repair Parts List

			Air Valve Assembly			
14 #	01		Part Number			
Item #	Qty.	Description	Aluminum	Stainless Steel	Nickle Plated	PTFE Coated
1	1	Air Valve Assembly (includes items 2-11)	031.V001.156	031.V001.110	031.V001.340	031.V002.309
2	1	Valve Body	095.V001.156	095.V001.110	095.V001.340	095.V001.309
3	1	Valve Body Gasket	P24-202			
4	1	Valve Sleeve	755.V001.148			
5	6	O-Ring			06.360	
6	1	Valve Spool Assembly (Includes items 7)			001.000	,
7	6	Glyde Ring Assembly			-204F	
8	1	Air Valve Screen	P24-210	P34-210	P24-210	P24-210
9	2	End Cap Gasket			-205	
10	2	End Cap	P34-300		4-300	P34-300TC
11	13	Mounting Screws		S1	001	
		Ce	nter Section Assembl	у		
Item #	Qty.	Description	A I		lumber	DTEE Ocated
10	1	·	Aluminum D24 400DC ACV	Stainless Steel	Nickle Plated	PTFE Coated
12 13		Center Block Assembly (Includes item 13)	P24-400DC ASY	SP24-400 196.V003.110	P24-401NP	P24-401TC
	2	Air Chamber	196.V003.156		196.V003.340	196.V003.309
14 15	2	Air Chamber Gasket	D04 440	360.70	001.465 SP24-110	
16	8	Bolt Pilot Sleeve Assembly (include items 18 & 19)	P24-110	755 \/(
17					002.000	
	6	O-Ring			01.360 37.080	
18 19	1	Retaining Ring Pilot Spool Assembly (Includes item 21)			002.000	1
20	7	O-Ring			23.360	1
21	1	Muffler Elbow			5-0072	1
22	1	Muffler Elbow			33.000	
22			gm Assembly / Elasto		33.000	
			igin 7 toocinisiy 7 Elaott		lumber	
Item #	Qty.	Description	Alum		Cast Iron	Stainless
			P24-103			
23	1	Main Shaft			-103	
24	1 2	Diaphragm (See Below Material Chart)		V2:	-103 27xx	
24 25	2	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3)		V226B, V226BNP,	-103 27xx V226BTC, SV226B	
24 25 26	2	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer		V22 V226B, V226BNP, P24	-103 27xx V226BTC, SV226B 501	
24 25 26 27	2	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate	VB:	V22 V226B, V226BNP, P24 226	I-103 27xx V226BTC, SV226B I-501 SVE	3226
24 25 26 27 28	2 2 2 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart)	VB:	V22 V226B, V226BNP, P24 226 722.0	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx	
24 25 26 27 28 29	2 2 2 4 8	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart)	VB:	V226B, V226BNP, P24 226 722.0 (See I	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2)	
24 25 26 27 28	2 2 2 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart)		V226B, V226BNP, P24 226 722.0 (See I	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx	
24 25 26 27 28 29	2 2 2 4 8	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart)	VB2	V226B, V226BNP, P24 226 722.0 (See I	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx	
24 25 26 27 28 29 30	2 2 2 4 8 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart)	Wet End Assembly	V226B, V226BNP, P24 226 722.0 (See I 050.0	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx	3226
24 25 26 27 28 29 30	2 2 2 4 8 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description	Wet End Assembly	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron	3226 Stainless
24 25 26 27 28 29 30 Item #	2 2 2 4 8 4 Qty.	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber	Wet End Assembly	V22 V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx	3226 Stainless 196.V001.110
24 25 26 27 28 29 30 Item #	2 2 2 4 8 4 Qty. 2 20	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt	Wet End Assembly	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156 170.069.330	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron	Stainless 196.V001.110 170.069.115
24 25 26 27 28 29 30 Item # 31 32 33	2 2 2 4 8 4 Qty. 2 20 16	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt	Wet End Assembly	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156 170.069.330 170.085.330	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron	Stainless 196.V001.110 170.069.115 170.085.115
24 25 26 27 28 29 30 Item # 31 32 33 34	2 2 2 4 8 4 Qty. 2 20 16 36	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer	Wet End Assembly	V226B, V226BNP, P24 226 722.0 (See l 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115
24 25 26 27 28 29 30 Item # 31 32 33 34 35	2 2 2 4 8 4 4 Qty. 2 20 16 36 36 36	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut	Wet End Assembly Alum 196.V0	V226B, V226BNP, P24 226 722.0 (See l 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36	2 2 2 4 8 4 4 Qty. 2 20 16 36 36 36 1	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold	Wet End Assembly Alum 196.V0	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110
24 25 26 27 28 29 30 Item # 31 32 33 34 35	2 2 2 4 8 4 4 Qty. 2 20 16 36 36 36	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold	Wet End Assembly Alum 196.V0	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37	2 2 4 8 4 Qty. 2 20 16 36 36 1	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor	Wet End Assembly Alum 196.V0 518.V0 518.V0 ner Material Specifica	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37	2 2 4 8 4 4 Qty. 2 20 16 36 36 36 1 1 1 terial	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N"	Wet End Assembly Alum 196.V0 518.V0 518.V0 618.V0 The standard of the sta	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Se	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 ee Note 2 Below)"
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37	2 2 4 8 4 4 Qty. 2 20 16 36 36 1 1 1 terial opene	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N"	Wet End Assembly Alum 196.V0 518.V0 518.V0 518.V0 mer Material Specifica "Ball P/N" 050.005.365	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Seat Seat Seat Seat Seat Seat Seat Seat	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 See Note 2 Below)" 84.365
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37	2 2 4 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227BN	### Standard	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Seat Seat O-Ring (Seat Seat O-Ring (Seat Seat O-Ring (Seat Seat O-Ring (Seat O-Ring	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 ee Note 2 Below)" 84.365 84.360
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna	2 2 4 8 8 4 4 Qty. 2 20 16 36 36 1 1 1 terial opene a Nitrile citon	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227BN V227VT	### State	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.363	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V009.010 "Seat O-Ring (Se 560.0 560.0 560.0	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 See Note 2 Below)" 84.365 84.360 84.363
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna	2 2 4 8 8 4 4 Qty. 2 20 16 36 36 1 1 1 terial openee a Nitrile citon ordel	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227ND	### STAND ST	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.363 722.091.364	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V009.010 "Seat O-Ring (Seat Seat O-Ring (Seat O-Ring (Se	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 ee Note 2 Below)" 84.365 84.360 84.363 84.364
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Mai Neo Buna	2 2 4 8 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227ND N/A (see PTFE fitted manual)	### State	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.364 722.091.600	I-103	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 ee Note 2 Below)" 84.365 84.360 84.363 84.364 61.608
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Mai Neo Buna V No P Santo	2 2 4 8 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227ND V227VT V227ND N/A (see PTFE fitted manual) V227TPEXL	### State	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.363 722.091.364 722.091.600 N/A	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V009.010 "Seat O-Ring (Se 560.0 560.0 560.0 720.0 560.0	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 See Note 2 Below)" 84.365 84.360 84.363 84.364 61.608 84.364
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna V No P Sant	2 2 4 8 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Suction Manifold Flastor "Versa-Dome Diaphragm P/N" V227N V227N V227ND N/A (see PTFE fitted manual) V227TPEXL V227TPEFG	518.V0 518.V0 518.V0 600.005.365 050.005.363 050.005.364 050.010.600 050.005.354 N/A	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.364 722.091.600	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Seat O	Stainless
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna V No P Sante	2 2 4 8 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227ND V227VT V227ND N/A (see PTFE fitted manual) V227TPEXL	### State	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.363 722.091.364 722.091.600 N/A N/A	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Seat O	Stainless 196.V001.110 170.069.115 170.085.115 901.038.115 SV185B 518.V008.110 518.V009.110 See Note 2 Below)" 84.365 84.360 84.363 84.364 61.608 84.364
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna V No P Sante Hy Alun	2 2 4 8 4 8 4 Qty. 2 20 16 36 36 1 1 terial oprene a Nitrile fiton ordel TFE oprene ytrel minum	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227N V227ND V227VT V227ND N/A (see PTFE fitted manual) V227TPEXL V227TPEFG N/A	518.V0 518.V0 518.V0 6518.V0 6	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.364 722.091.364 722.091.364 722.091.360 N/A N/A 722.091.150 (See Note 1 Below) 722.091.080	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Se 560.0 560.0 560.0 720.0 560.0 N	Stainless
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Ma Neo Buna V No P Sante Hy Alun	2 2 4 8 8 4 4	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Suction Manifold Flastor "Versa-Dome Diaphragm P/N" V227N V227N V227ND N/A (see PTFE fitted manual) V227TPEXL V227TPEFG	518.V0 518.V0 518.V0 600.005.365 050.005.363 050.005.364 050.010.600 050.005.354 N/A	V226B, V226BNP, P24 226 722.0 (See I 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.363 722.091.364 722.091.364 722.091.50 (See Note 1 Below) 722.091.080 (See Note 1 Below)	I-103 27xx V226BTC, SV226B I-501 SVE 91.xxx Note 2) 05.xxx Iumber Cast Iron 196.V001.010 518.V008.010 518.V009.010 "Seat O-Ring (Se 560.0 560.0 560.0 720.0 560.0 N	Stainless
24 25 26 27 28 29 30 Item # 31 32 33 34 35 36 37 Mai Neo Buna V No P Sante H Alur Carbo	2 2 4 8 4 8 4 Qty. 2 20 16 36 36 1 1 terial oprene a Nitrile fiton ordel TFE oprene ytrel minum	Diaphragm (See Below Material Chart) Inner Diaphragm Plate (See Note 3) Bumper Washer Outer Diaphragm Plate Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart) Valve Ball (See Below Material Chart) Description Water Chamber Water Chamber Bolt Manifold Bolt Washer Nut Discharge Manifold Suction Manifold Elastor "Versa-Dome Diaphragm P/N" V227N V227N V227ND V227VT V227ND N/A (see PTFE fitted manual) V227TPEXL V227TPEFG N/A	518.V0 518.V0 518.V0 6518.V0 6	V226B, V226BNP, P24 226 722.0 (See 050.0 Part N inum 01.156 170.069.330 170.085.330 901.038.330 V185B 08.156 09.156 tions Seat P/N 722.091.365 722.091.360 722.091.364 722.091.364 722.091.364 722.091.360 N/A N/A 722.091.150 (See Note 1 Below) 722.091.080	I-103	Stainless


Notes:

- 1.) The metallic seat material is to match the water chamber material. In addition to this seat, (8) O-Rings are needed.(Ref Note 2) 2.) These (8) O-Rings are only used with metallic fitted seats. The O-Ring material is to match the diaphragm material.
 3.) The inner diaphragm plate is to match the inner chamber material (Ref. Note 4) 4.) V = Aluminum, TC = PTFE Coated, NP = Nickel Plated, SV = Stainless Steel

VERSA-MATIC® VME40msm-rev1011

3: EXP VIEW

Composite Repair Parts Drawing (PTFE Fitted)





Composite Repair Parts List (PTFE Fitted)

Air Valve Assembly							
Item #	Qty.	Description	Part Number				
iteili#	Qty.	•	Aluminum	Stainless Steel	Nickle Plated	PTFE Coated	
1	1	Air Valve Assembly (includes items 2-11)	031.V001.156	031.V001.110	031.V001.340	031.V001.309	
2	1 1	Valve Body	095.V001.156	095.V001.110	095.V001.340	095.V001.309	
3	1 1	Valve Body Gasket			24-202		
4	1 1	Valve Sleeve		/55	.V001.148		
5	6	O-Ring		500	0.206.360		
<u>6</u> 7	1 6	Valve Spool Assembly (Includes items 7)		1/5	.V001.000		
	6	Glyde Ring Assembly			34-204F	D24 240	
<u>8</u> 9	2	Air Valve Screen End Cap Gasket	P24-210	P34-210	24-205	P24-210	
10	2	End Cap Gasket End Cap	P34-300			P34-300TC	
11	13	Mounting Screws	F34-300		S1001	F34-3001C	
11	ΙJ	Cer	nter Section Asser		31001		
					t Number		
Item #	Qty.	Description	Aluminum	Stainless Steel	Nickle Plated	PTFE Coated	
12	1	Center Block Assembly (Includes item 13)	P24-400DC ASY	SP24-400	P24-401NP	P24-401TC	
13	2	Main Shaft O-Ring	, , , , , ,	P24-403			
14	2	Air Chamber	196.V003.156	196.V003.110	196.V003.340	196.V003.309	
15	2	Air Chamber Gasket	100.7000.100	360	.V001.465	100.1000.000	
16	8	Bolt	P24-110		SP24-110		
17	1	Pilot Sleeve Assembly (include items 18 & 19)		755	.V002.000		
18	6	O-Ring			0.101.360		
19	1	Retaining Ring	Ì		5.037.080		
20	1	Pilot Spool Assembly (Includes item 21)		775	.V002.000		
21	7	O-Ring			0.023.360		
22	1	Muffler Elbow		P ²	26-0072		
23	1	Muffler		530	0.033.000		
		Diaphra	gm Assembly / Ela				
				Par	t Number		
Item #	Qty.	Description		E 2 Piece		FUSION	
				Cast Iron Stainless	Aluminum	Cast Iron Stainless	
24	1 1	Main Shaft		P24-102		P24-103F	
25	2	Diaphragm		V227TF		V227F	
26		Back Up Diaphragm		227TFB	ļ	N/A	
27	2	Inner Diaphragm Plate (See Note 3)	V226B, V226BI	NP, V226BTC, SV226B	204 504	N/A	
28	2	Bumper Washer			24-501	NI/A	
29 30	2	Outer Diaphragm Plate Valve Seat (See Below Material Chart)	,	SVB226	2.091.xxx	N/A	
31	8	Valve Seat (See Below Material Chart) Valve Seat O-Ring (See Below Material Chart)	<u> </u>		ee Note 2)		
32	4	Valve Ball (See Below Material Chart)	1	(SE	0.005.xxx		
JZ	4		Wet End Assembl		J.00J.XXX		
			Wet End Assembl		t Number		
Item #	Qty.	Description	Aluminu	m C:	ast Iron	Stainless	
33	2	Water Chamber	196.V001.		V001.010	196.V001.110	
34	20	Water Chamber Bolt	100001.	170.069.330		170.069.115	
35	16	Manifold Bolt	ĺ	170.085.330		170.085.115	
36	36	Washer	901.038.330			901.038.115	
37	36	Nut	V185B		SV185B		
38	1	Discharge Manifold	518.V008.156 518.V008.010		518.V008.110		
39	1	Suction Manifold	518.V009.156 518.V009.010			518.V009.110	
			ner Material Speci				
Mat	terial	"Versa-Dome Diaphragm P/N"	"Ball P/I	N" S	eat P/N	"Seat O-Ring (See Note 2 Below)"	
Neoprene		V227N	050.005.3	365 722	.091.365	560.084.365	
	a Nitrile	V227BN	050.005.3		.091.360	560.084.360	
	iton	V227VT	050.005.3		.091.363	560.084.363	
Nordel		V227ND	050.005.3		.091.364	560.084.364	
PTFE					091.600	720.061.608	
		N/A (see PTFE fitted manual)	050.010.6				
P ⁻ Santo	TFE oprene	V227TPEXL	050.005.3		N/A	560.084.364	
P ⁻ Santo	TFE			354	N/A N/A		
P ⁻ Santo Hy	TFE oprene	V227TPEXL	050.005.3	722	N/A N/A 1.091.150	560.084.364	
Santo Hy Alun	TFE oprene ytrel	V227TPEXL V227TPEFG	050.005.3 N/A	722 (See N 722	N/A N/A .091.150 ote 1 Below) .091.080	560.084.364 N/A	
Santo Hy Alun Carbo	TFE oprene ytrel minum	V227TPEXL V227TPEFG N/A	050.005.3 N/A N/A	722 (See N 722 (See N 722	N/A N/A 0.091.150 ote 1 Below)	560.084.364 N/A N/A	

- 1.) The metallic seat material is to match the water chamber material. In addition to this seat, (8) O-Rings are needed. (Ref Note 2) 2.) These (8) O-Rings are only used with metallic fitted seats. The O-Ring material is to match the diaphragm material. 3.) The inner diaphragm plate is to match the inner chamber material (Ref. Note 4) 4.) V = Aluminum, TC = PTFE Coated, NP = Nickel Plated, SV = Stainless Steel



Written Warranty

5 - YEAR Limited Product Warranty

Quality System ISO9001 Certified • Environmental Management Systems ISO14001 Certified

Versa-Matic warrants to the original end-use purchaser that no product sold by Versa-Matic that bears a Versa-Matic brand shall fail under normal use and service due to a defect in material or workmanship within five years from the date of shipment from Versa-Matic's factory.

~ See complete warranty at http://www.versamatic.com/pdfs/VM%20Product%20Warranty.pdf ~

DECLARATION OF CONFORMIT

DECLARATION DE CONFORMITE • DECLARACION DE CONFORMIDAD • ERKLÄRUNG BEZÜGLICH EINHALTUNG DER VORSCHRIFTEN DICHIARAZIONE DI CONFORMITÀ • CONFORMITEITSVERKLARING • DEKLARATION OM ÖVERENSSTÄMMELSE EF-OVERENSSTEMMELSESERKLÆRING • VAATIMUSTENMUKAISUUSVAKUUTUS • SAMSVARSERKLÄRING DECLARAÇÃO DE CONFORMIDADE

MANUFACTURED BY:

FABRIQUE PAR: FABRICADA POR: HERGESTELLT VON: FABBRICATO DA: VERVAARDIGD DOOR: TILLVERKAD AV: FABRIKANT: VALMISTAJA: PRODUSENT: FABRICANTE:

VERSA-MATIC®

Warren Rupp, Inc. A Unit of IDEX Corporation 800 North Main Street P.O. Box 1568 Mansfield, OH 44901-1568 USA

Tel: 419-526-7296 Fax: 419-526-7289



PUMP MODEL SERIES: E1 SERIES, E2 SERIES, E3 SERIES, E4 SERIES, E40 SERIES, E5 SERIES, E7 SERIES, E8 SERIES, RE SERIES AND U2 SERIES

This product complies with the following European Community Directives:

2006/42/EC

EN 809

on Machinery, according to Annex VIII

Dieses produkt erfüllt die folgenden Vorschriften der Europäischen Gemeinschaft: Questo prodotto è conforme alle seguenti direttive CEE:

Dir produkt voldoet aan de volgende EG-richtlijnen:

Denna produkt överensstämmer med följande EU direktiv:

Versa-Matic, Inc., erklærer herved som fabrikant, at ovennævnte produkt er i overensstemmelse med bestemmelserne i Direkktive:

Tämä tuote täyttää seuraavien EC Direktiivien vaatimukstet:

Dette produkt oppfyller kravene til følgende EC Direktiver:

Este produto está de acordo com as seguintes Directivas comunitárias:

This product has used the following harmonized standards to verify conformance:

Ce materiel est fabriqué selon les normes harmonisées suivantes, afin d'en garantir la conformité:

Este producto cumple con las siguientes directrices de la comunidad europa:

Ce produit est conforme aux directives de la Communauté européenne suivantes:

Este producto cumple con las siguientes Directrices de la Comunidad Europea:

Dieses produkt ist nach folgenden harmonisierten standards gefertigtworden, die übereinstimmung wird bestätigt:

Questo prodotto ha utilizzato i seguenti standards per verificare la conformita':

De volgende geharmoniseerde normen werden gehanteerd om de conformiteit van dit produkt te garanderen:

För denna produkt har följande harmoniserande standarder använts för att bekräfta överensstämmelse:

Harmoniserede standarder, der er benyttet:

Tässä tuotteessa on sovellettu seuraavia yhdenmukaistettuja standardeja:

Dette produkt er produsert i overenstemmelse med fløgende harmoniserte standarder:

Este produto utilizou os seguintes padrões harmonizados para varificar conformidade:

AUTHORIZED/APPROVED BY:

Approuve par: Aprobado por: Genehmigt von: approvato da: Goedgekeurd door: Underskrift:

Valtuutettuna: Bemyndiget av: Autorizado Por: Dave Roseberry

Engineering Manager

DATE: August 10, 2011

FECHA: DATUM: DATA: DATO: PÄIVÄYS:

VMOR 044FM

05/27/2010 REV 05

VERSA-MATIC

WWW.VERSAMATIC.COM

DECLARATION OF CONFORMITY WITH ATEX 95 DIRECTIVE



Date of Issue: 22 April, 2008

Reference No: SH071304-ATEX-01P and

HS032204-ATEX-01P

Quality System Registration No: ISO 9001-2000

Directive: 94/9/EC 23 March 1994 Annex VIII

Conforming Apparatus: Air-Operated Metal

Double Diaphragm Pumps for Use In Potentially

Explosive Atmospheres

Hazardous Location Applied: 1. II 3/2GD c T5

T5 fluids up to 95° C

2. I M2 c

fluids up to 95° C

Manufacture: Warren Rupp, Inc., A Unit of IDEX Corporation

800 North Main Street, P.O. Box 1568

Mansfield, OH 44901-1568

USA.

On File With: LCIE

33, avenue du Général Leclerc F 92260 Fontenay-aux-Roses

FRANCE

Harmonized Standards Applied: BS EN 13463-1:2001 Non-Electrical Equipment

Potentially Explosive Atmospheres-Part 1 Basic

Methods and Requirements

prEN 13463-5 Non-Electrical Equipment for Potentially Explosive Atmospheres-Part 5 Protection by Constructional Safety

avid Roseberry

We hereby certify that the above apparatuses described above conforms with the protection requirements of Council Directive 94/9/EC of 23 March 1994 Annex VIII on the approximation of the laws of the Member States Concerning Equipment and Protective Systems Intended for use in Potentially Explosive Atmospheres

DATE/OF REVISION/TITLE: 27 May 2010

Dave Roseberry Engineering Manager



